
ASSEMBLY GUIDE

Dispenser and Bracket Components



Open Gate to Remove Reservoir



Attach Dispenser to Bracket





Attach Dispenser to Bracket

You will need the dispenser bracket, dispenser, dispenser key, the provided, small allen wrench, 4 screws and 2 washers to mount the dispenser to the bracket correctly.

NOTE: The dispenser also comes with optional screws and anchors for wall mounting that are not needed for the stand assembly.

Unlock the dispenser at the top with one of the (2) provided keys and open.

Push gate up to unhinge and move to the right to access the reservoir and feed tube.

Remove reservoir and tube by pulling straight out.

Insert screws into the (2) upper holes, do not tighten yet. Just screw in enough to slide the dispenser onto the screws. Line up bottom holes to bracket holes and attach the (2) screws with washers. Center dispenser left to right and then tighten all four screws.

Re-install the reservoir and tube into the dispenser by sliding straight in. IMPORTANT: In order for the dispenser to function properly, you need to make sure that the white tab of the tube slides in on the outside of the black frame.

Close gate and lid, remove blue nozzle cover, lock the lid to dispenser and the assembly is ready.

FINISHED STAND



Assemble Base and Pole

Base plate has a hole in the middle for attaching to the stand pole.

countersunk to accommodate the screw.

place screw through the bottom plate and re-attach to the pole. Tighten with the provided allen wrench.


Attach Dispenser to Pole

Attach the dispenser bracket to

Remove screw from top of pole bracket and turn bracket around so flange is facing up. Screw bracket back into place. Attach the sign holder with the wingnut connection to the bracket. Sign holder can be adjusted for vertical or horizontal format by simply turning.








Base Bottom View Completed Base

Mount Dispenser to Pole



NOTE: Bottom of the base is

Remove screw from pole bottom,



Adjustable

Attach the Sign Holder





Dispenser requires (6) AA batteries to operate. Batteries load in the right side of dispenser. The dispenser can use most hand sanitizer gels that are made for dispensers. (Batteries and hand sanitizer are not included)